AIRHALO DESKMATE
Air Sanitiser

Model AHD01: Step-by-Step Control Guide

Gold Medal
inventions Geneva

AIRHALO DESKMATE
Air Sanitiser

Index

Connection Guide

Web Panel Guide

Hotspot Customisation

## WIFI Local Area Network (WLAN) on Home Router

AIRHALO DESKMATE
## Air Sanitiser

Connection Guide

Connecting to Deskmate with Windows 7 OS

Step 1: Click This icon on your toolbar

Step 2: Click "All Settings" or "Network".
If click "Network" go to Step 4

Step 3: Click Network & internet

AIRHALO *DESKMATE*
# Air Sanitiser

Step 4: Click WIFI

Step 5: Click Show available networks

Step 6: Click on Deskmate Hotspot You can find the name of the SSID by looking at the product label located on the bottom of the Deskmate.

AIRHALO DESKMATE
Air Sanitiser

Step 7: Click "Connect"

Step 08: In your web browser of choice select the URL/Search field and type the default homepage IP address of the hotspot: **192.168.100.1** and press enter

AIRHALO DESKMATE
Air Sanitiser

Step 09: At Deskmate login screen Enter default username and Password:

" admin " (lowercase no quotes)

Click LOGIN.

You have now reached the control panel of the Deskmate

See Page 13 for control panel overview

AIRHALO DESKMATE
Air Sanitiser

Connecting to Deskmate by Mobile (Android) Device

Download App from Google Store:
https://play.google.com/store/apps/details?id=com.aonetech.airhalo

Step 1: Swipe down the notification bar.

Locate the "Gear" symbol. Click it.

Step 2: Locate your WIFI menu

i.e. Network and internet

Click into the menu

AIRHALO *DESKMATE*
Air Sanitiser

Step 3: Locate WIFI, Click into the sub-menu

Step 4: Turn on the WIFI

Step 5: Select the Deskmate hotspot

You can find the name of the SSID by looking at the product label located on the bottom of the Deskmate.

AIRHALO *DESKMATE*
Air Sanitiser

Step 6:

If there is two SSID with the same name. Choose the one that does not require a password. i.e. the SSID without the Lock symbol

11:43	Wi-Fi
Use Wi-Fi	
	🔒
	🔒
16734184	🔒
524524	🔒
AHD01S001001	🔒
AHD01S001001	
CSL	
CSL Auto Connect	🔒
	🔒
Incu-Bio MFP01	🔒

11:45

192.168.100.1

CGI3:login page
192.168.100.1

192.168.100.1

Step 7:

In your web browser of choice select the URL/Search field and type the default homepage IP address of the hotspot:
192.168.100.1 and press enter

AIRHALO DESKMATE
Air Sanitiser

Step 8:
At Deskmate login screen
Enter default username and
Password:

" admin " (lowercase no quotes)

Click LOGIN.

You have now reached the control panel of the Deskmate

See Page 13 for control panel overview

Connecting to Deskmate by Android App

GET IT ON
Google Play

Step 1: Download & install
Air Halo Deskmate Control App
https://play.google.com/store/apps/details?id=com.aonetech.airhalo

Step 2: Click on the Air Halo Deskmate
App icon on your android device

Air Halo

Step 3: Press the "Refresh"
button to search for Air Halo
Deskmate's within range

AIRHALO DESKMATE
Air Sanitiser

Air Halo

AHD01S001001

Signal Good

AHD01S001002

Signal Good

Step 4: The available Deskmate's you can connect to will be displayed.

"Signal Good" means the connection is strong.

"Signal bad" means the connection is bad and you should move closer to the device

Step 5: Clicking on the specific Deskmate's will initiate connection to the device

Air Halo

AHD01S001001

Signal Good

AHD01S001002

Connecting

Connecting to
AHD01S001001

AIRHALO *DESKMATE*
Air Sanitiser

Web Panel Guide

Login Panel

Air Halo Sanitizer Login

DEVICE INFO

This Deskmate's unique ID/Host name → Device Name: admin

LAN: 0.0.0.0

When connect to a local WIFI network (WLAN) the IP of the connected Deskmate will be shown here → WLAN: 0.0.0.0

HotSpot WLAN: 192.168.100.1 ← IP address of this Deskmate's Hotspot homepage

VERSION 1.0.0

Welcome to Air Halo Control - AHD01/AHS01 -

Username

Password

LOGIN

Control Panel

Logout button

Advance Panel Button

Control Panel

OFF ── Off ── ON ← Turn Deskmate ON/OFF manually

Deskmate's current Mode status. i.e. Manual/Timer/ Program/ECON →

Mode Status: **Power Status:**

← Current sanitisation power level. i.e. OFF/Silent/Low /Normal/Boost

Mode	Power Level
MANUAL	Silent
TIMER	Low
PROGRAM	Normal
ECON	Boost

Switch between the different modes

Manually control the sanitisation power level.

ONE TECH A-ONETECH LIMITED © 2021

AIRHALO *DESKMATE*
Air Sanitiser

Advance Panel

Logout button

Back Button

Deskmate's unique Name

New Login Password

Customise settings for each mode

Adjust Deskmate's device settings

Adjust LED brightness

Software reset to factory default

Select LED brightness from dropdown menu

AIRHALO *DESKMATE*
Air Sanitiser

Timer Panel

Automatically switch off Deskmate after a set duration

Current set timer default is 30mins ➡

Set hours (0 – 24hrs) and/or Set Minutes (0 – 59mins) ➡

Program Panel

Automatically switch Deskmate on & off with set power levels at specific times

Currently scheduled Programs Click "delete" at the end of each line to disable a schedule

⬅ Set time of schedule

⬅ Set sanitisation power level Off/Silent/Low/Normal/Boost

⬅ Set day or days

Clock Panel

Configure Deskmate to the correct Timezone for Program mode to operate accurately

Currently set Time and Date

Set date

Set time

Firmware Panel

Update the Deskmate software.
!Warning! Only operate this function when directed by Customer Support !Warning!

Current firmware installed

Select firmware file from a local source

AIRHALO *DESKMATE*
Air Sanitiser

Network Panel

Configure the HOTSPOT and WIFI Local Area Network that will allow you to connect to a home router

HOTSPOT CONNECTION

SSID: AHD01S001158

Customise Hotspot name.
Default: Model No. + Serial
AHD01_XXXXXXXXX

PASSWORD: XXXXXXXX

Customise Hotspot password
Default: none

IP: 192.168.100.1

Customise Hotspot IP Address

SELECT AUTHORISATION: OPEN

Customise authorisation type

Hotspot MAC Address

MAC ADDRESS:
CA:FE:30:FF:CE:41

AUTO CHANNEL

Apply

Search compatible available WIFI network

WLAN CONNECTION

SEARCH WIFI

SETUP WLAN

SSID: AHD01S001277

Select available WLAN you can connect

PASSWORD: Network KEY

Enter password for WLAN selected

WIFI Gateway

GATEWAY: 192.168.3.1   IP: 192.168.3.1

Apply   Reboot

Hotspot Customisation

Customisable fields

Channels refer to the WIFI bandwidth the Hotspot operates on.
This is set to "Auto" and cannot be manually altered

Customisation of the WIFI hotspots allows personalisation of:
SSID name is customisable to a 64 alpha-numeric entry
Password is customised to a 24 alpha-numeric entry

After completion the customisation of the Hotspot, click "Apply" to complete the changes.

Select the type of WIFI authorisation: WPA2 Personal, WPA2, Open or Shared

A-ONETECH LIMITED © 2021

AIRHALO DESKMATE
Air Sanitiser

WIFI Local Area Network (WLAN) on Home Router

Connecting to a WLAN from a home router can be configure in the Network panel, under WLAN connection.

Step 01: Click the "Search WIFI" button to list compatible WLAN to connect to.

WLAN CONNECTION

SEARCH WIFI

SETUP WLAN

Step 02: Open the list to select the desired WLAN available

SSID: AHD01S001277

Step 03: Entry WLAN password

PASSWORD: Network KEY

GATEWAY: 192.168.3.1   IP: 192.168.3.1

Assigned WLAN Gateway is shown here

Assigned IP Address On WLAN is shown here

Apply   Reboot

Step 04: Apply settings to connect to the WLAN

You can connect multiple Deskmate's to the same WLAN, each one are uniquely identified by it's Device name.
Repeat the above steps for each additional Deskmate you are connecting